

## Glossary of Terms

- Q The energy losses of relative damping (ratio of stored to dissipated energy or ratio of reactive to resistive energy).
- F<sub>s</sub> Free air resonance of driver in Hz.
- Q<sub>ms</sub> Mechanical Q.
- V<sub>as</sub> Volume of air equivalent to driver from the rest position.
- C<sub>ms</sub> Mechanical compliance of a loud speaker piston.
- M<sub>ms</sub> Moving mass of total loud speaker piston assembly.
- X<sub>max</sub> The maximum linear excursion of a loud speaker.
- S<sub>d</sub> Surface area of the cone.
- D<sub>ia</sub> The piston diameter of a loud speaker.
- Q<sub>es</sub> Electrical Q of a system.
- R<sub>e</sub> DC resistance.
- L<sub>e</sub> VC inductance.
- P<sub>e</sub> Maximum input power.
- Q<sub>ts</sub> Total Q of the system.
- Sens Sensitivity. An efficiency measurement in dB's.
- V<sub>c</sub> Volume of a closed or sealed enclosure
- V<sub>b</sub> Volume of a vented enclosure.
- F<sub>c</sub> The resonant frequency of a closed or sealed system
- F<sub>b</sub> The resonant frequency of a vented system
- F<sub>3</sub> The half-power (-3dB) frequency of a loud speaker enclosure
- Q<sub>tc</sub> The Q of a loud speaker at F<sub>c</sub> in a closed box, considering both it's electrical and mechanical resistance.
- Q<sub>L</sub> The Q of a vented box, resulting from all box losses.
- D<sub>V</sub> Diameter of vent.
- L<sub>V</sub> Length of vent.
- H Height.
- W Width.
- D Depth